


VT-47 ULTRA TX-RX UNIT TOP Layer




VT-47 ULTRA TX-RX UNIT BOTTOM Layer




Layer







VT-47 ULTRA KEY UNIT TOP Layer



VT-47 ULTRA KEY UNIT BOTTOM Layer



VT-47 ULTRA KEY UNIT TOP Layer



VT-47 ULTRA KEY UNIT BOTTOW Layer